

## Certificate of Analysis

### KPL 10X Tris-Glycine Transfer Buffer

**PART Code** 5460-0012 (51-10-02)  
**Lot No.** 10510359  
**SIZE** 5 L

**DESCRIPTION** Western blot transfer buffer. To prepare 1X Towbin buffer for Western blot transfer, mix 100 mL KPL 10X Tris-Glycine Transfer Buffer, 200 mL methanol, and 700 mL reagent quality water. Do not adjust pH.

**FORM/STORAGE** Liquid. Store at room temperature.

**CONTENTS** Supplied as a 5L container(s).

**STABILITY** Product is stable for one year from date of receipt when stored at room temperature.

**DATE OF MANUFACTURE** 21 JUL 2020

Approval:

A handwritten signature in blue ink that reads "Kimberly M. Wedel".

07 AUG 2020

Quality Assurance

Date